## KV-M1430D/M1431D

## SERVICE MANUAL

## AEP Model KV-M1430D

Chassis No. SCC-D85H-A

Chassis No. SCC-D85J-A



## BE-2A CHASSIS

2 batteries IEC designation

Approx.  $55 \times 18 \times 185$ mm (w/h/d) Approx. 100g including batteries

RM-694 Remote Commander (1) IEC designation R6 batteries (2)

R6 (size AA)

MODELS OF THE	E SAME SERIES
KV-M1430D/M1430E	KV-M1620D
KV-M1430B/M1430A	KV-M1420D
KV-M2140D/M2141D	

Remote control system infrared control

## **SPECIFICATIONS**

[RM-694]

**Dimensions** 

Weight

Power requirements

Supplied accessories

## [KV-M1430D/M1431D]

Television system B/G/H

Color system

PAL/SECAM

Channel coverage

VHF: E2-E12

UHF: E21-E69

CABLE TV: S01-S20

HYPER: S21-S41

Picture tube

Black Trinitron tube

Approx. 36.8 cm (14 inches)

(Approx.33.7cm picture measured diagonally)

90° degree deflection

Inputs

Ö- 21-pin connector: CENELEC standard

RGB input

V A Audio/Video input jacks

phono jacks

⊕ S-Video input jack

Outputs

Headphones jack: minijack

21-pin connector: TV output

Sound output

5 W (Music)

Power consumption 47 Wh (KV-M1430D)

Dimensio ns

48 Wh (KV-M1431D) Approx. 366x363x409 mm (w/h/d)

Weight


Approx. 10.5 kg




Design and specifications are subject to change without notice.



## 21 pin connector (-;;; , ;; -2/-;; )





Pin No.	1	2	Signal	Signal level
1	0	0	Audio output B (right)	Standard level: 0.5Vrms Output impedance: Less than 1kohm*
2	0	0	Audio input B (right)	Standard level: 0.5Vrms Input impedance: More than 10kohms*
3	0	0	Audio output A (left)	Standard level: 0.5Vrms Output Impedance: Less than 1kohm*
4	0	0	Ground (audio)	
5	0	0	Ground (blue)	
6	0	0	Audio Input A (left)	Standard level: 0.5Vrms Input impedance: More than 10kohms*
7	0	•	Blue input	0.7V ± 3dB, 75ohms, positive
8	0	0	Fu ction select (AV control)	High state (9.5 - 12V): Part mode Low state (0 - 2V): TV mode Input impedance: More than 10kohms Input capacitance: Less than 2 nF
9	0	0	Ground (green)	
10	0	0	Open	
11	0	•	Green	Green signal: $0.7V \pm 3dB$ , 750hms, positive
12	0	0	Open	
13	0	0	Ground (red)	
14	0	0	Ground (branking)	
15	0	-	Red input	0.7V ± 3dB, 75ohms, positive
15	-	0	(S signal) croma input	$0.3V \pm 3$ dB, 75ohms, positive
16	0	•	Blanking input (Ys signal)	High state (1 - 3V) Low state (0 - 0.4V) Input impedance: 75ohms
17	0	0	Ground (video output)	
18	0	0	Ground (video input)	-
19	0	0	Video output	1V ± 3dB, 75ohms, positive Sync: 0.3V ( - 3, +10dB)
20	0	-	Video input	1V ± 3dB, 75ohms, positive Sync: 0.3V ( - 3, +10dB)
20		0	Video Input/Y (S signal)	1V ± 3dB, 75ohms, positive Sync: 0.3V ( - 3, +10dB)
21	0	0	Common ground (plug	, shield)

○ connected ● unconnected (open)

\* at 20Hz - 20kHz

## 4 pin connector ( 🕣)

Pin No.	Signal	Signal level
1	Ground	
2	Ground	
3	Y (S signal) input	1V ± 3dB, 75ohms, positive Sync: 0.3V ; dB
4	C (S signal) input	$0.3V \pm 3$ dB, 750hms, positive

## **TABLE OF CONTENTS**

Section	<u>Title</u>	<u>Page</u>	Section	<u>Title</u>	Page
1. GEN	ERAL		4. CIRC	UIT ADJUSTMENTS	
1-1. 1-2. 1-3. 1-4. 1-5. 1-6. <b>2. DIS</b> A 2-1. 2-2. 2-3. 2-4.	Switching On/Off Presetting TV Operation Teletext Operation (KV-M1431D only) Optional Connections/Operations Additional Information  ASSEMBLY Rear Cover Removal V Board Removal (KV-M1431D only) Service Position Picture Tube Removal	4 5 6 7 7 9	4-2. <b>5. DIAG</b> 5-1. 5-2. 5-3. <b>6. EXPL</b>	A Board Adjustments  V Board Adjustment (KV-M1431D only  RAMS  Circuit Boards Location  Schematic Diagrams and  Printed Wiring Boards  Semiconductors  CODED VIEW  CTRICAL PARTS LIST	y) · · · · · 16 · · · · · 18 · · · · · 28 · · · · · 30
3. SET	-UP ADJUSTMENTS				
3-1. 3-2. 3-3. 3-4.	Beam Landing	··· 12 ··· 13			

## CAUTION

SHORT CIRCUIT THE ANODE OF THE PICTURE TUBE AND THE ANODE CAP TO THE METAL CHASSIS, CRT SHIELD, OR CARBON PAINTED ON THE CRT, AFTER REMOVING THE ANODE.

## **SAFETY-RELATED COMPONENT WARNING!!**

COMPONENTS IDENTIFIED BY SHADING AND MARK A ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.


## SECTION 1 GENERAL

1-2. PRESETTING

## 1-1. SWITCHING ON/OFF

After you have completed the basic preparation your TV is ready to be connected to the mains power supply (220V AC, 50Hz).

How to turn the TV on




Θ|

## - PRINCE -

Automatic presetting of channels

After having installed the TV, you now need to preset TV channels. Up to 60 programme positions are at your disposal. For channel presetting use the buttons with the red symbols on the Remote Commander.



Action




The selected

-----IIIIIIIIIIII


You are now in the 5 preset mode. The programme number


Press both the ◆ SHIFT button and the ⇒ PRESET button simultaneously.

Result



₽	Press either the number buttons or PROGR +/- to select the programme number on which you want to preset the channel.	Note: in case of two digit numbers, first press -/, then the two numbers.	S bress both the ◆ SHIFT button and the ⊞ + or – button repeatedly, until the desired channel is tuned in:	Repeat steps 3 and 4 for all other cha
<b>\\\</b>			1	






	-
Press both the ◆ SHIFT and the ⇒ PRESET buttons simultaneously to store the channels.	

•		Ŷ
	Γ	<b>-</b>
channels.		

		þ
	]•	۰.
hannels		

	]
	<b>-</b>
anneis	_



•	P
ınne <del>l</del> s.	<b>□</b> +






































## All channels are now stored. The programme number stops flashing.












TRINITRON

RM-694

TRINITRON







The scale with the

Trequency band changes.









-4-

How to turn the TV off

Press & to enter standby

mode.

A Temporarily

4 4 4





























































































## 1-3. TV OPERATION



## How to skip programme positions

Since you have 60 programmes at your disposal, you may want to skip vacant programme positions, that means that they are skipped when you press the PROGR +/- buttons.

Action		Result
Press the 🌣	Press both the ♦ SHIFT button and the ⇒ PRESET button simultaneously.	You are now in 75 preset mode, the programme position flashes.
Use Pl progra skip.	Use PROGR + or - to select the programme position you want to skip.	The selected —30- programme position appears.
D Press the bu	Press both the • SHIFT button and the button C simultaneously.	
<b>4</b> Press the ⇒	Press both the SMIFT button and the SPRESET button simultaneously.	The programme 30 position is now skipped. You are back in TV mode.

o[] e[]

~ --

# How to fine tune a channel manually

If the reception of a stored channel is not satisfactory, you can fine tune the channel manually

both the ♦ SHIFT button and the EEB The channel is now line tuned.  - button simultaneously intil the tion is good.	
	 inel is now fine tuned.

TRINITRON RM-694

Note: By pressing the respective programme number the automatic fine tuning will be restored.



## How to select programmes

This section shows you how to use the convenient features available for  $\rho perating$  the  ${\rm TV}_{\rm c}$ 

Action	Result
Press PROGR +/- or the respective	The selected programme is displayed.
number button on the Remote	
Commander. In case of two digit	
numbers first press -/ and then the	
two respective number buttons.	
On the set:	
Press the + or - button for programme selection.	ection.

## How to adjust the volume

Θ

Action	Result
Press ∠ + or −.	The \(\array\) symbol and the level indicator are displayed on the screen. The volume is adjusted accordingly.
Muting of the sound	
Press button 4	The sound is switched off. Press the button again to restore the sound.
On the set: Press button © repeatedly in order to select the desired item, then adjust with the + or - button.	sct the desired item, then adjust with

## How to adjust the picture

Ä	Action	Result
_	Press button ® repeatedly, until the desired item is displayed ( <b>0</b> contrast, <b>0</b> colour intensity, <sup>©</sup> brightness).	The symbol and the respective bar display are displayed.
N	2 Press button + or	The selected picture item is adjusted accordingly.
4 -	Press button @ repeatedly in order to select the desired item, then adjust with the	of the desired item, then adjust with the

To return to factory-set levels + or - button.

## Press the + · + · button.

Other functions

RM-694

TRINITRON

## On-screen display

Press the 3 button to display the programme number on the screen and press the button a second time to make it disappear.

Selecting the signal of a connected device Press the C button to receive the signal of the device (e.g. a VTR) connected at the VGA connectors (front of the set) or the 21-pin connector (rear of the set). Press the  $\Box$  button to return to the IV mode.

## Time function

Press © to request the time. Press again to cancel the request (only if teletext is Sleep Timer broadcast).


Press the © button repeatedly until the required time period is displayed on the screen (30, 60, 90 minutes or 0 for cancelling the request). In this way you can select the time period after which the set switches itself automatically into standby-mode.

## -5-

ြေ

# 1-4. TELETEXT OPERATION (KV-M1431D only)

TV stations broadcast teletext programmes via the TV channels. To receive teletext programmes, use the buttons indicated in green on the Remote Commander.



# Select the channel which carries the teletext service you wish to view. Press @/@. Press @/@. India the teletext service you wish to view. The channel changes on the screen. The teletext service appears. The teletext service appears. The channel changes on the screen. The teletext service appears. The teletext service appears. The channel changes on the screen. The teletext service appears. The teletext service appears in a few seconds. The teletext channels: To change the teletext channels: First press ©/@.

Note If the signal of the TV channel is weak, teletext errors may often occur. The  $\Box$  button has no function on this set.

# How to use the Advanced Features of Teletext

Ном	Action	Result (on-screen dissilar)
Request the index page.	Press © (INDEX).	Not appears.
Access the next or preceding page.	Press @ (PAGE +) or @ (PAGE -).	The next or preceeding page appears.

How to	Action	Result
Superimpose the teletext display on the TV programme.	Press @ Once if you are in text mode, or press @ O twice if in TV mode.  To return to the normal teletext display press @ O again.	The teletext displays are superimposed on the TV programmes.
Prevent a teletext page from being updated or changed.	Press ⊕ (HOLD). To resume normal teletext reception, press ⊜! ❷ (TEXT/MIX).	The HOLD symbol
Enlarge the teletext display.	Press ® once to enlarge the upper half. Press twice to enlarge the lower half. Press again to restore the normal display.	word members enlarged.
Reveal concealed information (e.g. answers to a quiz).	Press © (REVEAL). Press again to conceal the information.	The information is revealed.
Watch the TV programme while	1. Request a new page.	The numbers are entered.
waning for a requested page to be displayed.	2. Press @ (TEXT CL).	The TV programme is displayed, and the requested page number and other teletext data appear at the top of the screen.
	3. When the requested page has been captured, the page number remains and the other data disappears.	P201
	4. Press  to view this page	The requested page is displayed.

# Some of the features may not be available depending on the Teletext service.

## How to use the FASTEXT Feature

FASTEXT feature allows you to access pages quickly with one key operation.

When a FASTEXT page is broadcast, a colour coded menu appears at the bottom of the screen. Each coloured prompt corresponds to the four coloured buttons of your Remote Commander.

## Operation


Action	Result
Press one of the coloured buttons which corresponds to the coloured prompt on the teletext.	The selected teletext page appears.

## Note

Correct FASTEXT operation dupends on the necessary signals sent from the TV station. Some TV stations may not send signals for the FASTEXT.

# 1-5. OPTIONAL CONNECTIONS/OPERATIONS

# How to connect additional Audio/video equipment



## How to view the Video input signal

Press button ⊕ repeatedly in order to select the desired input mode (⊕ for Audio/video signals from 21-pin EURO connector ⊕ or from the video/audio connectors V ⊕ A on the front; ⊕ for S-video signals from the S-video (4-pin DIN) connectors on the front). Press button ○ to return to TV mode.

# Press button € once, the symbols ○ ④. € will appear on the screen, then press the + button to select the desired video input mode. Press € and + buttons again to return to TV-mode.

On the set:

Video signals may be separated into Y (luminance or brightness) and C (chrominance) signals. Separating the Y and C signals prevents them from interfering with one another, and therefore improves picture quality (especially luminance). This TV is equipped with one S-video input jack through which these separated signals can be input S-video input (Y/C input)

When you have Audio/video equipment connected to both the A/V connectors and the 21-pin terminal, make sure that not both are switched on at the same time, otherwise the picture could be incomplete.
 In case of sound or picture distortions move the VTR away from the TV set.

RM-694

TRINITRON


□ di

٠ •

# 1-6. ADDITIONAL INFORMATION

## Parts Identification

TV Set - Front



This section briefly describes the buttons and controls on the TV set and on the Remote Commander. For more information.

## TV Set

Symbol	Function
Θ	Main power switch
Đ	Standby indicator
-/+	Programme selector
-/+	Sound and picture adjustment/input selection
c	Headphone jack (mini-jack)
φν	Video input jack
A Q	Audio input jack
4	S-video input jack
i¢.	21-pin connector (rear of set)
⊨	Aerial socket (rear of set)

## Remote Commander

Symbol	Function
ф	Button for switching the TV set into standby mode
0	Used to return to TV-mode from standby and video input modes
1-9, 0, -/	Number buttons – in case of two digit numbers first press button –/ and then two number buttons
PROGR +/-	Programme scanning buttons
-≎ and ♦	Preset mode on/off buttons
*	Functions only in combination with other buttons
<b>♦</b> and C	Button for clearing a programme position (in preset mode)
-/+ <b>₹</b> and <b>₹</b>	Buttons for manual fine tuning of a channel/presetting
*	Mute button
富	Select button for picture adjustment item
-/+	Buttons for adjusting picture items
÷ †	Button for resetting the picture adjustment items to standard
-/+ <b>Z</b>	Buttons for adjusting the volume
0	Button for activating the sleep timer
•	On/off button for onscreen display
6	Time feature (only for KV-M1431D)
	Teletext buttons (only for KV-M1431D)
	FASTEXT Buttons
ф	Button for selecting the video input mode

Note: Buttons not referred to in this index have no function.


## Troubleshooting


Here are some simple solutions to the problems which affect the picture and sound.

Problem	Solution
No picture (screen is dark), no sound	<ul> <li>Plug the TV in.</li> <li>Press Ø on the TV. (If Ø indicator is on, press ○ or the programme number on the Remote Commander).</li> <li>Check the aerial connection.</li> <li>Check if the selected video source is on.</li> <li>Turn the TV off for 3 or 4 seconds and then turn it on again using Ø.</li> </ul>
Poor or no picture (screen is dark), but sound good	. Adjust $\mathfrak{L},  \Phi, \Phi$ by pressing the + button after selecting with the $\boxdot$ button.
Good picture but no sound	<ul> <li>Press ∠ +.</li> <li>Disconnect the headphones.</li> <li>If I I is displayed on the screen, press II.</li> </ul>
No colour for colour programmes	<ul> <li>Adjust ⊕ with the + button after selecting with the ⊕ button.</li> <li>Press → • • on the Remote Commander.</li> </ul>
Remote Commander does not function	REPLACE THE BATTERIES

If you continue to have these problems, have your TV serviced by qualified personnel. Never open the casing yourself.


## **SECTION 2 DISASSEMBLY**






## 2-2. V BOARD REMOVAL (KV-M1431D ONLY)

## 2-3. SERVICE POSITION




## 2-4. PICTURE TUBE REMOVAL




## REMOVAL OF ANODE-CAP

NOTE: Short circuit the anode of the picture tube and the anode cap to the metal chassis, CRT chield or carbon painted on the CRT, after removing the anode.

## REMOVING PROCEDURES



① Turn up one side of the rubber cap in ② Using a thumb pull up the rubber cap the direction indicated by the arrow ③. firmly in the direction indicated by the arrow ⑤.




When one side of the rubber cap is separated from the anode button, the anode-cap can be removed by turning up the rubber cap and pulling up it in the direction of the arrow ©.

## • HOW TO HANDLE AN ANODE-CAP

- ① Don't hurt the surface of anode-caps with sharp shaped material!
- ② Don't press the rubber hardly not to hurt inside of anode-caps! A material fitting called as shatter-hook terminal is built in the rubber.
- Onn't turn the foot of rubber over hardly! The shatter-hook terminal will stick out or hurt the rubber.





## SECTION 3 SET-UP ADJUSTMENTS

- The following adjustments should be made when a complete realignment is required or a new picture tube is installed.
- These adjustments should be performed with rated power supply voltage unless otherwise noted. The controls and switch below should be set as follows unless otherwise noted:
  - ◆ CONTRASTcontrol ······ 80%(or Normal by commander)

☼ BRIGHTNESS control .... 50%

Perform the adjustments in order as follows:

- 1. Beam Landing
- 2. Convergence
- 3. Focus
- 4. Screen (G 2) and White Balance

Note: Test Equipment Required.

- 1. Color bar/Pattern Generator
- 2. Degausser
- 3. DC Power Supply
- 4. Digital multimeter
- 5. Oscilloscope

## Preparation:

- Set the side of the unit with the PICTUE TUBE so that it faces east or west in order to reduce the influence of external magnetic force.
- Turn the power switch for the unit ON and erase the magnetic force using a degausser..

## 3-1. BEAM LANDING

Demagnetize with a degausser

1. Input a raster signal with the pattern generator.

 $\begin{array}{c} CONTRAST \\ BRIGHTNESS \end{array} \bigg\} normal$ 

- 2. Turn the raster signal of the pattern generator to red
- 3. Move the deflection yoke backward, and adjust with the purity control so that red is in the center and blue and green are at the sides evenly. (Fig.3-1 - 3-3)
- 4. Move the deflection yoke forward, and adjust so that the entire screen becomes red. (Fig.3-1)
- 5. Switch over the raster signal to blue and blue and confirm the condition.
- 6. When the position of the deflection yoke is determined, tighten it with a deflection yoke mounting screw.
- 7. When landing at the corner is not right, adjust by using the disk magnets. (Fig.3-4)




Fig.3-1




Fig.3-2






Fig.3-3




## 3-2. CONVERGENCE

## Preparation:


- Before starting, perform FOCUS, H.SIZE, and V. SIZE adjustments.
- Set BRIGHTNESS control to minimum.
- Feed in the dot pattern.
- (1) Horizontal and Vertical Static Convergence



- 1. Adjust H.STAT VR to converge red, green and blue dots the in center of the screen. (Horizontal movement)
- 2. Adjust V. STAT magnet to converge red, green and blue dots in the center of the screen. (Vertical movement)
- 3. If the red, green and blue dots do not converge on the center of screen with H.STAT VR, perform horizontal convergence adjustment using H.STAT VR and V.STAT magnet as shown below. (In this case, H.STAT VR and V.STAT magnet effect each other.)
- Tilt the V.STAT magnet and adjust static convergence to open or close the V.STAT magnet.



4. When the V.STAT magnet is moved in the direction of arrow (a) and (b) red, green and blue dots move as shown below.




If the red and blue dot do not converge with green dots, perform following steps.

Move BMC magnet (a) to correct insufficient H.static convergence.

Rotate BMC magnet (b) to correct insufficient V.static convergence.


In either case, repeat Beam Landing Adjustment.




## (2) Dynamic Convergence Adjustment Preparation:

- Before starting perform Horizontal and Vertical static convergence Adjustment.
- 1. Slightly loosen deflection yoke screw.
- 2. Remove deflection yoke spacers.


- 3. Move the deflection yoke for best convergence as shown below.
- 4. Tighten the deflection yoke screw.
- 5. Install the deflection yoke spacers.



## (3) Screen-corner Convergence



## 3-4. SCREEN (G 2) and WHITE BALANCE



## Screen (G 2) Setting

- 1. Input dot signal from the pattern generator.
- 2. Set the picture BRIGHTNESS control to minimum level.
- 3. Apply 140 V DC to the cathodes of R,G and B from an external power power source.
- 4. While watching the picture, adjust the G 2 volume (RV703) immediately before fly-back line disappears.


## White Balance Adjustment

- 1. Input all-white signal from the pattern generator.
- 2. Adjust the BRIGHTNESS and COLOR controls to the standard level.
- 3. Adjust the following using RV 701 (B DRIVE) and RV 702 (G DRIVE)

In the following adjustments, the CONTRAST, COLOR and BRIGHTNESS controls are set to normal unless otherwise specified.

## SECTION 4 CIRCUIT ADJUSTMENTS

## 4-1. A BOARD ADJUSTMENTS




-Component side-


## TU AGC Adjustment (RV 503)

- 1. Tune in air signal.
- 2. Adjust AGC VR (RV 503) so that snow-noise and cross-modulation just disappear from the picture.

## **RV 504 H.CENT (HORIZONTAL CENTER)**




## **RV 801 H.SIZE (HORIZONTAL SIZE)**




## **RV 501 V.CENT (VERTICAL CENTER)**





## H.FREQ Adjustment (RV 502)

- 1. Input a PAL COLOR BAR signal, then connect an electrolytic capacitor (100  $\mu/16$  V) between pin and GND of IC 502.
- 2. Adjust RV 502 (H.FREQ) to stop scrolling of the picture in the horizontal direction.
- 3. After adjustment, remove the electrolytic capacitor.




## REF OSC 8.8 MHz Adjustment (CT 332)

- 1. Input a PAL COLOR BAR pattern.
- 2. Short circuit between pin of IC 331 and ground.
- 3. Adjust CT 332 to obtain color synchronizetion.
- 4. Remove the jumper wire from IC 331.


## BELL FILTER Adjustment (LV 301)

- 1. Input a SECAM COLOR BAR pattern.
- 2. Connect an oscilloscope to rhe Q 302 emitter.
- 3. Adhust LV 301 so that waveform becomes flat.




## SECAM DISCRI Adjustment (RV 331 R-Y L 331 B-Y)

- 1. Input a SECAM COLOR BAR pattern.
- 2. Connect an oscilloscope to pin ① of IC 301.
- 3. Adjust RV 331(R-Y) so that white and black parts of the waveform of pin ① becomes 0 lecel.
- 4. Connect an oscilloscope to pin 3 of IC 301.
- 5. Adjust L 331(B-Y) so that white and black parts of the waveform of pin 3 becomes 0 level.




## CHARACTER POSITION Adjustment (RV 001)

- 1. Input PAL COLOR BAR pattern.
- 2. Adjust RV 001 to position the charcter display at the point indicated by the arrow below.



## 4-2. V BOARD ADJUSTMENT (KV-M1431D Only)




## RGB LEVEL Adjustment (RV 01)

- 1. Set PICTURE to maximum.
- 2. Adjust RV01 till the RGB output becomes maximum.

MEMO	
<u></u>	
······································	

## 5-1. CIRCUIT BOARDS LOCATION



## 5-2. SCHEMATIC DIAGRAMS AND PRINTED WIRING BOARDS

## Note:

- All capacitors are in μF unless otherwise noted. pF: μμF 50 WV or less are not indicated except for electrolytic and tantalums.
- All resistors are in ohms.  $k\Omega = 1000 \Omega$  ,  $M\Omega = 1000 K\Omega$
- Indication of resistance, which does not have one for rating electrical power, is as follows.

Pitch: 5 mm Rating electrical power 1/4 W

- : nonflammable resistor.
- $\triangle$  : internal component.
- : panel designation, or adjustment for repair.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

: earth-ground. : earth-chassis.

• # : no mounted.


Note: The components identified by shading and mark number specified.

Reference i	nformatio	on
RESISTOR	: RN	METAL FILM
	: RC	SOLID
	: FPRD	NONFLAMMABLE CARBON
	: FUSE	NONFLAMMABLE FUSIBLE
	: RS	NONFLAMMABLE METAL OXIDE
	: RB	NONFLAMMABLE CEMENT
	: RW	NONFLAMMABLE WIREWOUND
	: ※	ADJUSTMENT RESISTOR
COIL	: LF-8L	MICRO INDUCTOR
CAPACITOR	: TA	TANTALUM
	: PS	STYROL
	: PP	POLYPROPYLENE
	: PT	MYLAR
	: MPS	METALIZED POLYESTER
	: MPP	METALIZED POLYPROPYLENE
	: ALB	BIPOLAR
	: ALT	HIGH TEMPERATURE
	: ALR	HIGH RIPPLE
FD 11		4.1 1 1 1 1 1

- Readings are taken with a color-bar signal input.
- Readings are taken with a 10MΩ digital multimeter.
- Voltage are dc with respect to ground unless otherwise noted.
- Voltage variations may be noted due to normal production tolerances.
- All voltages are in V.
- Circled numbers are waveform references.
- e seemen : B+ bus.
- signal path. (RF)

- A Board -

) I G	DÐE	DIG	)ĐE	TRANS	ISTOR
Đ002	E-10	Đ1301	B-10	Q305	B-6
Ð004	C-9	Ð1302	B-10	0307	B-6
Đ007	B-8	Ð1303	B-10	0310	A-3
0008	Ð-10	Ð1304	A-10	Q311	A-3
Đ009	B-8	Ð1305	A-10	Q401	B-1
Đ011	E-8	Ð1306	B-10	0457	Ð-1
Đ020	B-8	Ð1300	B-10	1	
Ð110		D1307	5-10	Q504	C-3
	C-5			0505	B-3
Đ301	C-6			0601	G-5
Ð302	A-2	I		Q801	F-4
Ð303	B-6			0802	H-3
Đ305	A-2	IC001	C-9	0803	F-3
Ð306	B-6	10002	Ð-9	Q1301	B-9
0313	A-3	10003	Ð-10	Q1302	B-10
Ð321	C-5	IC004	E-9	01303	B-10
Ð324	A-7	10005	B-8	01304	A-10
Đ334	B-6	IC102	B-5	Q1305	A-10
Đ402	A-1	10201	F-8	Q1306	B-10
Đ403	B-1	IC301	Ð-5		2 10
Đ404	B-1	10302	B-7		
Đ405	A-1	10331	C-7	VARI	ARLE
Đ406	C-1	IC501	Ð-2	RESI	
Đ411	A-1	10502	C-4	RV001	D-9
Đ417	Ð-1	10601	G-5	RV501	Ð-2
D418	A-4	10801	F-3	RV502	B - 4
Đ426	C-1	IC802	E-4	RV503	C-4
Đ427	C-1	10002	- ·	RV504	B-4
Đ450	B-5	_		RV505	Ð-2
Đ501	Ð-3			RV801	F-4
Đ503	E-4			114001	1 "+
Ð504	G-2	TRANS	ISTOR		
Ð519	C-8	Q001	Ð-8	-	
Ð601	F-7	Q003	0-9	TRIM	MER.
Ð602	F-6	Q003	Ð-10	CT332	C-7
Ð60Z	F-5	1		L1332	L-/
Ð603	E-4	Q005 Q006	B-8 C-8	The state of the s	
Đ604 Đ605		1			
£605	E-6	Q007	B-4		
	Ð-5	Q015	Ð-3		
Đ607	G-5	0016	Ð-10		
Đ608	H-5	Q017	E-9		
Ð609	G-5	0019	Ð-10		
Đ610	G-5	Q020	Ð-8		
Đ611	F-4	Q104	C-1		
D801	G-3	Q106	A-2		
Đ802	H-4	0107	A-2		
Ð803	G-4	Q112	A-7		
Đ805	G-1	Q114	B-5		
908G	F-1	Q115	A-6		
Ð807	F-3	Q123	A-2		
808G	E-3	Q141	C-3		
Ð810	E-1	0302	C-7		
Đ811	E-1	Q304	B-6		




The circuit indicated as left contains high voltage of over


600 Vp-p. Care must be paid to prevent an electric shock in inspection or repairing.

SYSTEM CONTROL, A/V OUT, H/V OUT, MEMORY, CHROMA


- A Board -

DIG	DÐE	OIG	)ĐE	TRANS	ISTOR
Đ002	E-10	Ð1301	B-10	0305	B-6
Đ004	C-9	Ð1302	B-10	0307	B-6
	B-8				
Đ007		Ð1303	B-10	Q310	A-3
0008	Ð-10	Ð1304	A-10	Q311	A-3
Đ009	B-8	Ð1305	A-10	0401	B-1
Đ011	E-8	Ð1306	B-10	0457	Ð-1
Đ020	B-8	Ð1307	B-10	Q504	C-3
Ð110	C-5			0505	B-3
Đ301	C-6			0601	G-5
Ð302	A-2	т		Q801	F-4
Đ303	B-6			0802	H-3
Đ305	A-2	IC001	C-9	Q803	F-3
Đ306	B-6	10001	Ð-9	Q1301	B-9
0313	A-3	10002	Ð-10		
				01302	B-10
Đ321	C-5	10004	E-9	Q1303	B-10
Đ324	A-7	10005	B-8	01304	A-10
Đ334	B-6	IC102	B-5	01305	A-10
Đ402	A-1	IC201	F-8	01306	B-10
Đ403	B-1	10301	Ð-5		
Đ404	B-1	10302	B-7		
Đ405	A-1	10331	C-7	VARI	able :
Đ406	C - 1	IC501	Ð-2	RESI	STOR
Đ411	A-1	10502	C-4	RV001	Ð-9
Đ417	Ð-1	10601	G-5	RV501	Ð-2
Đ418	A-4	10801	F-3	RV502	B-4
Ð426	C-1	10802	E-4	RV503	C-4
Đ427	C-1			RV504	B-4
Đ450	B-5	-		RV505	Ð-2
Đ501	Ð-3			RV801	F-4
Ð503	E-4	TOLLIC	10100		
Đ504	G-2	IHANS	ISTOR		
Ð519	C-8	Q001	Ð-8		
Đ601	F-7	0003	C-9	TRIM	1MER
D602	F-6	Q004	Ð-10	CT332	C-7
D603	F-5	Q005	B-8	01002	6 /
Đ604	E-4	0006	C-8		
Đ605	E-6	Q005	B-4		
Đ606	Ð-5	Q015	D-4 D-3		
Đ608 Đ607	G-5	Q015	Ð-10		
1	H-5	l .			
£608		Q017 Q019	E-9		
	G-5	Q020	Ð-10		
Đ610	G-5		Ð-8		
Đ611	F-4 .	Q104	C-1		
Đ801	G-3	Q106	A-2.		
Đ802	H-4	Q107	A-2		
Đ803	G-4	Q112	۸-7		
Đ805	G-1	Q114	B-5		
D806	F-1	Q115	A-6		
Đ807	F-3	Q123	A-2		
9808	E-3	Q141	0-3		
Đ810	E-1	0302	C-7		
Ð811	E-1	Q304	B-6		
Đ820	F-4			1	












3-






## A BOARD WAVEFORMS




50Vp-p (V )	1.7Vp-p ( H)	5.2 Vp-p (V )
22		
2.0Vp-p (V)	1.8 Vp-p (H)	2.8 Vp-p(H)
29	23	27
M		
1.7Vp-p (10MHz)	200Vp-p(H)	4.2 Vp-p (V ) JK.>-A <wavelist>-2</wavelist>




11 | 12 | 13 | 14 |




- V Board -







## **BOARD WAVEFORMS**




- J1 Board -




## MC-Service






- C Board -




-c..

11 12 13 14 V [TEXT] C [R, G, B OUT] J1 [JACK]


- V Board -






BOARD WAVEFORMS

V901 A34JBU 10X PICTURE





- J1 Board -




MC-Service

- C Board -





## 5-3. SEMICONDUCTORS




## 2SÐ2096-EF



ĐAN202K MA152WK



ANOĐE



ERC06-155

GP08Đ U05G



SPR-54MVW




ĐAP202K




ĐA204K 155226



ERA83-006 RÐ5.1ES-B2 RÐ5.6ES-B2 RÐ6.8ES-B2 RÐ8.2ES-B3 1SS119 1SS133



RGP02-17 RGP10G RU-3AM



KBU4JL-6088 RBV-406H-01



MA3051 MA3056M MA3068M RÐ5.1M-B2 RÐ5.6M-B2 RÐ6.8M-B2




## **SECTION 6 EXPLODED VIEW**

## NOTE:

- Items with no part number and no description are not stocked because they are seldom required for routine service.
  The construction parts of an assembled part are indicated with a collation number in the remark column.
- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

The components identified by shading and mark A are critical for safety. Replace only with part number specified.



REF.NO. PART NO.	DESCRIPTION	REMARK	REF.NO. PART NO.	DESCRIPTION	REMARK
12 1-452-277-00 13 *4-385-422-01 14 *A-1638-022-A 15 *4-374-912-01	DOOR ORNAMENT, DOOR (KV-M1430D ONLY) ORNAMENT, DOOR (KV-M1431D ONLY) JI BOARD SPEAKER PLATE, TOP CUSHION, PICTURE TUBE PICTURE TUBE (A34JBU10X) SCREW (5), TAPPING SPACER, DY DEFLECTION YOKE (Y14NDA2) MAGNET, BMC HOLDER, LEAD C BOARD, COMPLETE	au 1. de 1. Hari H. Au	*A-1632-073-A 21	COVER, REAR A BOARD, COMPLETE A BOARD, COMPLETE SWITCH, PUSH (AC P BUTTON, POWER TRANSFORMER ASSY, TUNER (BT-3C421) TI HOLDER, AC CORD CORD, POWER (WITH PLATE, INSULATION CLIP, LEAD WIRE MAGNET, DISK; 10MM MAGNET, ROTATABLE PERMALLOY ASSY, CO BAND, BINDING	(KV-M1431D ONLY) OWER) FLYBACK (UX-1620) EKE4X001A NOISE FILTER)  DISK; 15MM Ø NVERGENCE

## **SECTION 7 ELECTRICAL PARTS LIST**



The components identified by shading and mark A are critical for safety.

Replace only with part number specified.

.

- Items marked " \* " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.

When indicating parts by reference number, please include the board name.

CAPACITORS

COILS

• MF : μF, PF : μμF

• MMH : inH, UH : μH

## RESISTORS

- All resistors are in ohms
  F: nonflammable

		•	F: nonflam	mable						
REF.NO	. PART NO.	DESCRIPTION			REMARK	REF.NO.	PART NO.	DESCRIPTION		REMARK
	*A-1632-074-A *A-1632-073-A	*********	**** Lete (KV-M14			C128 C130 C131 C131	1-163-025-11 1-136-171-00 1-164-232-11 1-163-029-11	CERAMIC CHIP 0.001MF FILM 0.33MF CERAMIC CHIP 0.01MF CERAMIC CHIP 0.0047MF	5% 10%	50V 50V 50V 50V
	4-200-399-01 4-200-407-01 4-201-057-01 *4-341-751-01 *4-341-752-01	SPACER, IC HOLDER, LED COVER, FUSE EYELET EYELET				C133 C134 C135 C136 C138 C139	1-164-232-11 1-106-365-00 1-163-033-00	CERAMIC CHIP 0.01MP  MYLAR 0.0082MF CERAMIC CHIP 0.022MF CERAMIC CHIP 0.022MF METAL GLAZE 0 5% CERAMIC CHIP 0.01MF	10% 10% 1/10% 10%	50V 400V 50V 50V
	<cap< td=""><td>ACITOR&gt;</td><td></td><td></td><td></td><td>i</td><td></td><td></td><td></td><td></td></cap<>	ACITOR>				i				
C001 C002 C003 C004 C005	1-126-101-11 1-106-220-00 1-163-031-11 1-123-382-00 1-126-103-11	MYLAR CERAMIC CHIP		20% 10% 20% 20%	16V 100V 50V 50V 16V	C140 C141 C142 C143 C144	1-163-017-00 1-163-017-00 1-163-017-00 1-163-809-11 1-163-017-00	CERAMIC CHIP 0.0047MF CERAMIC CHIP 0.0047MF CERAMIC CHIP 0.0047MF CERAMIC CHIP 0.047MF CERAMIC CHIP 0.0047MF	10% 10% 10% 10% 10%	50V 50V 50V 25V 50V
C006 C007 C009 C010 C012	1-163-117-00 1-124-907-11 1-124-907-11 1-163-117-00 1-126-233-11	CERAMIC CHIP ELECT ELECT CERAMIC CHIP ELECT	10MF 10MF	5% 20% 20% 5% 20%	50V 50V 50V 50V 50V	C145 C146 C147 C148 C149	1-163-809-11 1-163-809-11 1-163-809-11 1-164-665-11 1-124-119-00	CERAMIC CHIP 0.047MF CERAMIC CHIP 0.047MF CERAMIC CHIP 0.047MF CERAMIC CHIP 0.039MF BLECT 330MF	10% 10% 10% 10% 20%	25V 25V 25V 50V 16V
C018 C020 C021 C023 C024	1-163-031-11 1-124-903-11 1-124-907-11 1-124-907-11 1-124-907-11	CERAMIC CHIP ELECT ELECT		20% 20% 20% 20%	50V 50V 50V 50V 50V	C151 C154 C157 C163 C201	1-124-907-11 1-164-232-11 1-124-927-11 1-164-232-11 1-126-233-11	ELECT 10MF CERAMIC CHIP 0.01MF ELECT 4.7MF CERAMIC CHIP 0.01MF ELECT 22MF	20% 10% 20% 10% 20%	50V 50V 50V 50V 50V
C025 C026 C030 C037 C038	1-126-233-11 1-124-903-11 1-124-903-11 1-163-034-00 1-163-009-11	ELECT ELECT ELECT CERAMIC CHIP CERAMIC CHIP	22MF 1MF 1MF 0.033MF	20% 20% 20%	50V 50V 50V 50V 50V	C202 C203 C204 C206 C207	1-124-925-11 1-163-009-11 1-124-480-11 1-163-011-11 1-124-925-11	ELECT 2.2MF CERAMIC CHIP 0.001MF ELECT 470MF CERAMIC CHIP 0.0015MF ELECT 2.2MF	20% 10% 20% 10% 20%	50V 50V 25V 50V 50V
CO39 CO41 CO55 CO58 CO59	1-163-117-00 1-124-478-11 1-163-075-00 1-163-077-00 1-163-031-11	CERAMIC CHIP BLECT CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	100PF 100MF 0.047MF 0.1MF	5% 20% 10%	50V 25V 50V 25V 50V	C208 C209 C210 C302 C303	1-126-104-11 1-124-910-11 1-106-228-00 1-163-059-00 1-163-059-00	ELECT 470MF ELECT 47MF MYLAR 0.22MF CERAMIC CHIP 0.01MF CERAMIC CHIP 0.01MF	20% 20% 10%	35V 50V 100V 50V 50V
C062 C063 C101 C102 C103	1-126-101-11 1-163-017-00 1-124-477-11 1-124-910-11 1-163-105-00	ELECT CERAMIC CHIP ELECT ELECT	100MF 0.0047MF 47MF 47MF	20% 10% 20% 20% 5%	16V 50V 16V 50V 50V	C304 C305 C306 C307 C308	1-163-038-00 1-124-910-11 1-106-220-00 1-163-038-00 1-124-910-11	CERAMIC CHIP 0.1MF ELECT 47MF MYLAR 0.1MF CERAMIC CHIP 0.1MF ELECT 47MF	20% 10% 20%	25V 50V 100V 25V 50V
C104 C105 C106 C107 C112		CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP ELECT	0.039MF 0.039MF 0.01MF 47MF	10% 10% 20% 5%	50V 50V 50V 16V 50V	C309 C311 C312 C313 C314	1-163-099-00 1-163-133-00 1-163-121-00 1-163-105-00 1-163-103-00	CERAMIC CHIP 18PF CERAMIC CHIP 470PF CERAMIC CHIP 150PF CERAMIC CHIP 33PF CERAMIC CHIP 27PF	5% 5% 5% 5%	50V 50V 50V 50V 50V
C114 C115 C120 C123 C125	1-163-109-00 1-163-031-11 1-163-173-00 1-163-117-00 1-124-917-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	47PF 0.01MF 47PF	5% 5% 5% 20%	50 V 50 V 50 V 50 V 50 V	C316 C317 C318 C319 C321	1-163-377-11 1-163-093-00 1-164-232-11 1-163-038-00 1-163-038-00	CERAMIC CHIP 100PF CERAMIC CHIP 10PF CERAMIC CHIP 0.01MF CERAMIC CHIP 0.1MF CERAMIC CHIP 0.1MF	5% 5% 10%	50V 50V 50V 25V 25V



The components identified by shading and mark  $\Lambda$  are critical for safety.

Replace only with part number specified.

REF.NO.	PART NO.	DESCRIPTION			REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
C323 C329	1-131-367-00	CERAMIC CHIP	22MF	10% 10%	50V 16V	C520	1-163-033-00				50 <b>V</b>
C330 C331 C332	1-163-117-00 1-124-927-11 1-130-783-00	CERAMIC CHIP ELECT MYLAR	100PF 4.7MF 0.33MF	5% 20% 10%	50 <b>V</b> 50 <b>V</b> 100 <b>V</b>	L C525	1-131-377-00 1-106-228-00 1-106-216-00	MYLAR Mylar	10MF 0.22MF 0.068MF	10% 10% 10%	100V 100V 100V
C333 C334	1-163-037-11 1-163-063-00	CERAMIC CHIP	0.022MF	10% 10%	25V 50V	C527	1-124-910-11 1-164-232-11	CERAMIC CHIP		20% 10%	50V 50V
C335 C336 C337	1-163-063-00 1-163-119-00 1-130-834-00	CERAMIC CHIP CERAMIC CHIP MYLAR	0.022MF 120PF 1MF	10% 5% 10%	50V 50V 63V	C529 C530 C531 C532	1-163-117-00 1-163-197-00 1-163-113-00 1-163-117-00	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	470PF 68PF	5% 5% 5%	50V 50V 50V 50V
C338 C339 C340	1-106-220-00 1-106-220-00 1-162-568-11		0.1MF 0.1MF 0.33MF	10% 10% 10%	100V 100V 16V	C536 C537	1-163-038-00	ELECT	4.7MF	20%	50 V 50 V 25 V
C341 C343	1-130-783-00 1-106-383-00	MYLAR	0.33MF 0.047MF	10% 10%	100V 100V	C540 C601 A	1-163-111-00 .1-161-964-61 .1-161-964-61	CERAMIC CHIP	56PF	5%	50V 250V 250V
C344 C345 C346	1-130-783-00 1-163-187-00 1-163-033-00	MYLAR CERAMIC CHIP CERAMIC CHIP	180PF	10% 5%	100 <b>V</b> 50 <b>V</b> 50 <b>V</b>		1-162-599-12	CERAMIC	0.0047MF	20%	250V 250V 400V
C347 C348	1-163-037-11 1-163-037-11	CERAMIC CHIP CERAMIC CHIP	0.022MF	10% 10%	25V 25V	C605 C606	1-161-754-00 1-136-637-11 1-106-367-00	CERAMIC	0.001MF 0.047MF 0.01MF	10% 10% 10%	2KV 630V 400V
C349 C352 C353	1-163-037-11	CERAMIC CHIP MYLAR CERAMIC CHIP	0.022MF 0.022MF	10% 10% 10%	25V 250V 25V	C609	1-161-753-00 1-124-347-00	CERAMIC ELECT	470PF 100MF	10% 20%	3KV 160V
C354 C355	1-163-037-11 1-163-037-11	CERAMIC CHIP	0.022MF	10% 10%	25V 25V	C612 C614	1-124-557-11 1-102-228-00 1-126-101-11	ELECT CERAMIC ELECT	1000MF 470PF 100MF	20% 10% 20%	25V 500V 16V
C356 C357 C358	1-163-237-11 1-163-031-11 1-124-556-11	CERAMIC CHIP CERAMIC CHIP ELECT	0.01MF 2200MF	5% 20%	50V 50V 16V	ļ	1-126-233-11 .1-136-879-11 .1-164-246-11		0.68MF	20% 20%	50V 300V
C359 C360	1-163-125-00 1-124-903-11		1 MF	5% 20%	50V 50V	i CbZ4	.1-164-246-11 1-161-754-00 .1-136-879-11 1-164-246-11	CERAMIC	0.0022MF 0.001MF 0.68MF	20% 10% 20%	400V 2KV 300V
C361 C367 C370 C388	1-163-237-11 1-163-031-11 1-126-233-11 1-106-220-00	CERAMIC CHIP CERAMIC CHIP ELECT MYLAR	0.01MF 22MF 0.1MF	5% 20% 10%	50V 50V 50V 100V	C801	1-136-559-11	MYLAR	0.0022MF 0.0047MF	20% 10%	400V 400V
C401 C403	1-124-910-11	ELECT CERAMIC CHIP	47MF	20% 5%	50V 50V	C803 C804	1-102-212-00 1-102-244-00 1-126-101-11 .1-136-076-11	CERAMIC Elect	820PF 220PF 100MF 0.0085MF	10% 10% 20% 3%	500 <b>V</b> 500 <b>V</b> 16 <b>V</b> 2 <b>KV</b>
C404 C430 C431	1-163-031-11	CERAMIC CHIP CERAMIC CHIP ELECT	0.01MF 0.33MF 47MF	20%	50V 25V 50V	C806	1-106-389-00	MYLAR	0.082MF	10% 10%	200V 2KV
C432 C433	1-163-031-11 1-126-233-11	CERAMIC CHIP	0.01MF		50V 25V	1 (011	1-136-932-11 1-106-367-00 1-136-540-11	rilm	0.82MF 0.01MF 0.82MF	5% 10% 5%	100V 400V 160V
C434 C451 C475	1-163-197-00 1-126-233-11		470PF 22MF	-070	50V 50V 50V	C812 C813	1-124-634-11 1-163-009-11	ELECT CERAMIC CHIP	1MF	20%	250 <b>V</b> 50 <b>V</b>
C476 C490	1-106-216-00	ELECT	0.068MF 47MF	10% 20%	100V 50V	C814 C815 C816	1-126-542-11 1-126-233-11 1-102-228-00	ELECT ELECT CERAMIC	4.7MF 22MF 470PF	20% 20% 10%	160V 50V 500V
C499 C501 C502 C503	1-163-205-00 1-163-181-00 1-163-005-11	CERAMIC CHIP CERAMIC CHIP CERAMIC CHIP	100PF 470PF	10% 5% 10%	50V 50V 50V	C817	1-123-948-00 1-106-375-12	MYLAR	22MF 0.022MF	20% 10%	250V 250V
C504 C505	1-163-181-00 1-124-122-11 1-126-233-11		100PF 100MF 22MF	5% 20% 20%	50V 50V 50V	C819 C820 C821	1-162-114-00 1-162-318-11 1-126-101-11	CERAMIC CERAMIC ELECT	0.0047MF 0.001MF 100MF	10% 20%	2KV 500V 16V
C506 C507 C508	1-126-228-00 1-124-557-11 1-163-117-00	MYLAR	0.22MF 1000MF	10% 20% 5%	100V 25V 50V	C822 C823 C824	1-162-318-11 1-126-233-11 1-124-913-11	CERAMIC ELECT ELECT	0.001MF 22MF 470MF	10% 20% 20%	500 <b>V</b> 50 <b>V</b> 50 <b>V</b>
C509 C510	1-162-568-11 1-163-081-00	CERAMIC CHIP	0.33MF	10%	16 V 25 V	C825 C826 C840	1-106-367-00 1-137-146-11 1-124-902-00	MYLAR FILM ELECT	0.01MF 0.15MF 0.47MF	10% 10% 20%	400V 250V 50V
C511 C512 C513	1-163-117-00 1-106-216-00 1-124-927-11	CERAMIC CHIP MYLAR		5% 10% 20%	50V 100V 50V	C1301 C1302	1-164-232-11 1-126-101-11	CERAMIC CHIP	0.01MF 100MF	10 <b>%</b> 20 <b>%</b>	50V 16V
C514 C515	1-136-298-00 1-163-035-00	CERAMIC CHIP		5%	100V 50V	C1303 C1304 C1305	1-163-809-11 1-163-809-11 1-126-233-11	CERAMIC CHIP CERAMIC CHIP ELECT	0.047MF	10% 10% 20%	25V 25V 50V
C516 C517	1-163-113-00 1-163-033-00	CERAMIC CHIP CERAMIC CHIP		5%	50V 50V	1	1-163-005-11	CERAMIC CHIP		10%	50 <b>V</b>

The components identified by shading and mark  $\Lambda$  are critical for safety.

Replace only with part number specified.



REF.NO.	PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION	REMARK
CD101	<filt< td=""><td>DISCRIMINATOR, CERAMIC</td><td></td><td>D601 ♠</td><td>8-719-976-64</td><td>DIODE MA152WK DIODE KBU4JL-6088 DIODE RGPO2-17 DIODE UO5G</td><td>ju jeda in</td></filt<>	DISCRIMINATOR, CERAMIC		D601 ♠	8-719-976-64	DIODE MA152WK DIODE KBU4JL-6088 DIODE RGPO2-17 DIODE UO5G	ju jeda in
SWF101	1-527-840-00	FILTER, SURFACE WAVE FILTER, CERAMIC  ECTOR>		D604 D605 D606 D607 D608	8-719-300-33 8-719-980-78 8-719-300-33	DIODE EGP2OG DIODE RU-3AM DIODE ERA83-006 DIODE RU-3AM DIODE RU-3AM	
CNA21	*1-560-290-00	PLUG. CONNECTOR (2.5MM PITCH)		D609	8-719-911-55	DIODE UOSG	
CNA22 CNA42 CNA43	*1-568-878-51 *1-565-394-11 *1-565-394-11	PIN, CONNECTOR 3P PIN, BOARD TO BOARD CONNECTOR PIN, BOARD TO BOARD CONNECTOR PIN, CONNECTOR (5MM PITCH) 3P		D610 D611 D801 D802	8-719-303-49 8-719-945-80	DIODE U05G DIODE R2M DIODE ERC06-15S DIODE EGP20G	
CNA63 CNA64 CNA81	*1-508-786-00 *1-508-784-00 *1-508-768-00	PIN, CONNECTOR (POWER) PIN, CONNECTOR (5MM PITCH) 2P PIN, CONNECTOR (5MM PITCH) 1P PIN, CONNECTOR (5MM PITCH) 6P CONNECTOR PIN (DY) 6P		D803 D805 D806 D807 D808	8-719-300-33	DIODE RU-3AM DIODE RGPO2-17	
CNA83	*1-508-765-00	PIN, CONNECTOR (5MM PITCH) 3P		D810 D811	8-719-911-55 8-719-911-55	DIODE UOSG	
CT 332	<trii< td=""><td>MMER&gt;</td><td></td><td>D820 D1301 D1302</td><td>8-719-911-19 8-719-911-19 8-719-911-19</td><td>DIODE 1SS119 DIODE 1SS119</td><td></td></trii<>	MMER>		D820 D1301 D1302	8-719-911-19 8-719-911-19 8-719-911-19	DIODE 1SS119 DIODE 1SS119	
01332				! D1304	8-719-911-19 8-719-400-18	DIODE MAI52WK	
2000	<dio< td=""><td></td><td></td><td>  D1306</td><td>8-719-400-18 8-719-800-76 8-719-800-76</td><td>DIODE MAISZWA DIODE 1SS226 DIODE 1SS226</td><td></td></dio<>			D1306	8-719-400-18 8-719-800-76 8-719-800-76	DIODE MAISZWA DIODE 1SS226 DIODE 1SS226	
D002 D004 D007 D008 D009	8-719-914-44	DIODE SPR-54MVW DIODE DAP2O2K DIODE MA152WK DIODE RD5.1M-B2 DIODE RD5.1M-B2			<del< td=""><td>AY LINE&gt;</td><td></td></del<>	AY LINE>	
D011	8-719-911-19	DIODE 1SS119		DL301 DL130	1-236-062-11 1 1-415-613-11	MODULE, Y DELAY LINE DELAY LINE, Y	
D020 D101 D102 D103	8-719-911-19 8-719-110-03 8-719-110-03 8-719-110-03	DIODE 1SS119 DIODE RD7.5ES-B2 DIODE RD7.5ES-B2 DIODE RD7.5ES-B2		F601 /	<fus< td=""><td>E&gt; FUSE (H.B.C.) 4A/250V</td><td> <u> </u></td></fus<>	E> FUSE (H.B.C.) 4A/250V	<u> </u>
D104 D110	8-719-400-18	DIODE MA152WK DIODE RD5.1ES-B2		LOUI	1-533-230-11	HOLDER, FUSE; F601	
D301 D302 D303	8-719-914-44 8-719-800-76	DIODE DAP202K DIODE 1SS226 DIODE DAP202K		1,0001	<1 C>8-759-062-07	IC PCA84C840P/016	
D305 D306 D313 D321	8-719-800-76 8-719-400-18 8-719-800-76 8-719-109-89	DIODE 1SS226 DIODE MA152WK DIODE 1SS226 DIODE RD5.6ES-B2		I C002 I C003 I C004 I C005	8-759-043-86 8-749-922-13 8-759-805-37	IC ST24C02AB1 IC KEY-COOSV-F IC L78LRO5D-MA IC UPC574J	
D324	8-719-914-44	DIODE DAP202K DIODE 1SS119		1C102 1C201		IC TDA3827/V3 IC TDA7245	
D333 D334 D402 D403 D404	8-719-911-19 8-719-914-44 8-719-109-97 8-719-109-97 8-719-109-97	DIODE DAPZOZK DIODE RD6.8ES-B2 DIODE RD6.8ES-B2		1 C301 1 C302 1 C331	8-759-505-39 8-759-512-04	IC TDA4660V2 IC TDA3505-V1 IC TDA4650/V4	
D405	8-719-110-09	DIODE RD8.2ES-B3		1 C501	*4-389-343-01	IC UPC1488H SPRING; IC501	
D406 D411 D417 D418	8-719-110-09 8-719-109-97 8-719-914-44 8-719-914-44	DIODE RD6.8ES-B2 DIODE DAP202K		10601	8-759-515-72 8-749-901-65 *4-368-683-01	IC STR54041 SPRING: IC601	
D426 D427	8-719-911-19 8-719-911-19	DIODE 188119		1 C801 1 C802	8-759-945-58 8-759-604-39 *4-389-343-01	IC M5F78M12L	
D450 D501	8-719-109-97 8-719-109-97 8-719-300-33	DIODE RD6.8ES-B2 DIODE RU-3AM					
D503	8-719-911-19	DIODE 188119		1401	<ja 1-561-534-00</ja 		
D504	8-719-400-18	DIODE MA152WK		¦ J401	1-100-100-1	JOUNCE ATT	



The components identified by shading and mark A are critical for safety.

Replace only with part number specified.

REF.NO	. PART NO.	DESCRIPTION		REMARK	REF.NO.	PART NO.	DESCRIPTIO	N -	REMARK
J1401	4501	1.	N (L TYPE) 2P		9303 9304 9305	8-729-230-49 8-729-230-49 8-729-230-49	TRANSISTOR	2SC2712-YG	
L001 L102 L103 L105 L106	1-408-409-00 1-408-409-00 1-408-399-00 1-410-872-21 1-408-415-00	INDUCTOR INDUCTOR INDUCTOR INDUCTOR INDUCTOR INDUCTOR INDUCTOR	10UH 10UH 1.5UH 10UH 33UH 12UH 10UH 68UH 220UH		Q307 Q310 Q311 Q401 Q457	8-729-230-49 8-729-216-22	TRANSISTOR TRANSISTOR TRANSISTOR TRANSISTOR	2SC2712-YG 2SA1162-G 2SC2712-YG 2SA1162-G	
L107 L301 L302 L303 L331	1-408-410-00 1-408-409-00 1-408-419-00 1-408-425-00 1-404-554-11	INDUCTOR INDUCTOR INDUCTOR INDUCTOR COIL	12UH 10UH 68UH 220UH		Q504 Q505 Q601 Q801 Q802	8-729-230-49 8-729-216-22 8-729-906-74 8-729-119-80 8-729-925-64	TRANSISTOR 1 TRANSISTOR 1 TRANSISTOR 1 TRANSISTOR 1	2SA1162-G BC637-16 2SC2688-LK BU508AS2	
L404 L406 L407 L501 L502	1-408-397-00 1-408-417-00 1-410-872-21 1-404-493-31 1-408-408-00	INDUCTOR INDUCTOR INDUCTOR COIL INDUCTOR	1UH 47UH 10UH 8.2UH 15UH 2.7MMH 2.7MMH 4.7MMH 82UH 10MMH 1UH		Q803 Q1301 Q1302	*4-389-343-01 8-729-202-03 *4-389-343-01 8-729-216-22 8-729-901-06	SPRING; Q802 TRANSISTOR 2 SPRING; Q803 TRANSISTOR 2 TRANSISTOR I	2 2SD1408-Y 3 2SA1162-G DTA144EK	
L506 L801 L802 L804 L805	1-408-411-00 1-407-365-00 1-420-872-00 1-459-856-11 1-408-236-00	INDUCTOR COIL, CHOKE COIL, AIR CORE COIL, FERRITE INDUCTOR	15UH 2.7MMH		Q1304 Q1305 Q1306	8-729-901-01 8-729-230-49 8-729-901-01 8-729-901-01	TRANSISTOR I TRANSISTOR I TRANSISTOR I	OTC144EK OSC2712-YG OTC144EK OTC144EK	
L806 L807	1-408-236-00 1-410-067-21	INDUCTOR INDUCTOR	2.7MMH 4.7MMH		LOORI	<res< td=""><td>ISTOR&gt;</td><td>0 5</td><td>1 /100</td></res<>	ISTOR>	0 5	1 /100
L808 L809 L1001	1-408-226-00 1-407-504-00 1-408-397-00	I NDUCTOR I NDUCTOR I NDUCTOR	82UH 10MMH 1UH		JR004 JR005 JR006	1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 0 5% 0 5% 0 5% 0 5%	1/10W 1/10W 1/10W 1/10W
L1002	1-408-397-00	INDUCTOR	108		JR009 JR010	1-216-295-00	METAL GLAZE	0 5% 0 5%	
	<var< td=""><td>IABLE COIL&gt;</td><td></td><td></td><td>JR012</td><td>1-216-295-00</td><td>METAL GLAZE</td><td>0 5%</td><td>1/10W 1/10W 1/10W</td></var<>	IABLE COIL>			JR012	1-216-295-00	METAL GLAZE	0 5%	1/10W 1/10W 1/10W
	1-404-554-11				JR016	1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE	0 5% 0 5%	1/10W 1/10W
	<10	LINK>	N15) 0.6A		JR017 JR018	1-216-295-00 1-216-295-00	METAL GLAZE	0 5% 0 5%	1/10W 1/10W
PS801 <u>4</u>	<u>.</u> 1-532-679-91	LINK, IC (ICP-	N15) 0.6A		JR020 JR026	1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE	0 5% 0 5% 0 5% 0 5% 0 5%	1/10W 1/10W 1/10W
		NSISTOR>			JR027 JR028	1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE		
Q001 Q003 Q004 Q005	8-729-901-01	TRANSISTOR 2SC2 TRANSISTOR DTC1 TRANSISTOR 2SC2 TRANSISTOR DTA1	144EK 2712-yg		JKU30	1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE	0 5% 0 5% 0 5% 0 5%	1/10W 1/10W 1/10W 1/10W
Q006 Q007	8-729-922-66	TRANSISTOR 2SC2	2410SN		JR037	1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE	0 5% 0 5%	1/10W 1/10W
QO15 QO16 QO17 QO19	8-729-230-49 8-729-230-49 8-729-901-47 8-729-216-22 8-729-901-06	TRANSISTOR 2SC2 TRANSISTOR 2SC2 TRANSISTOR DTA1 TRANSISTOR 2SA1	2712-YG 43EK 162-G		JR039	1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 0 5% 0 5% 0 5%	1/10W 1/10W 1/10W
QO20	8-729-901-00	TRANSISTOR DTAI			JR041	1-216-295-00	METAL GLAZE	0 5%	(KV-M1431D ONLY) 1/10W (KV-M1431D ONLY)
Q101 Q102 Q103	8-729-901-47 8-729-901-47	TRANSISTOR DTAI TRANSISTOR DTAI TRANSISTOR DTAI	43EK 43EK 43EK			1-216-295-00		0 5%	1/10W (KV-M1431D ONLY)
Q104 Q106	8-729-230-49 8-729-230-49	TRANSISTOR 2SC2 TRANSISTOR 2SC2				1-216-295-00		0 5%	1/10W (KV-M1431D ONLY)
Q107 Q112 Q114	8-729-216-22 8-729-230-49 8-729-901-00	TRANSISTOR 2SA1 TRANSISTOR 2SC2 TRANSISTOR DTC1	162-G 712-YG 24EK		JR050 JR051		METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 0 5% 0 5%	1/10W 1/10W 1/10W
Q1 15 Q1 41 Q3 02	8-729-014-99	TRANSISTOR DTC1 TRANSISTOR BF95 TRANSISTOR 2SC2	9-AMMO		JR060 JR099	1-216-295-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 5% 0 5% 0 5% 0 5% 0 5%	1/10W 1/10W 1/10W 1/8W



REF.NO.	PART NO.	DESCRIPTION			REMARK	REF.NO.	PART NO.	DESCRIPTION				REMARK
JR102 JR103 JR104 JR105 JR106	1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 0 0	5% 5% 5% 5%	1/8W 1/8W 1/8W 1/8W 1/8W	R023 R024 R025 R026 R028	1-216-051-00 1-216-065-00 1-216-097-00 1-216-089-00 1-216-085-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1.2K 4.7K 100K 47K 33K	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
JR107 JR108 JR109 JR110 JR111	1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 0 0	5% 5% 5% 5%	1/8W 1/8W 1/8W 1/8W 1/8W	R029 R030 R031 R032 R033	1-216-041-00 1-216-077-00 1-216-073-00 1-216-057-00 1-216-057-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	470 15K 10K 2.2K 2.2K	5%% %%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%	1/10W 1/10W 1/10W 1/10W 1/10W	
JR117 JR118 JR119 JR123 JR125	1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 0 0	5% 5% 5% 5%	1/8W 1/8W 1/8W 1/8W 1/8W	R034 R035 R038 R040 R041	1-216-238-00 1-216-077-00 1-216-073-00 1-216-081-00 1-216-081-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	47K 15K 10K 22K 22K	5% 5% 5% 5%	1/8W 1/10W 1/10W 1/10W 1/10W	
JR126 JR127 JR128 JR129 JR130	1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 0 0	5% 5% 5% 5%	1/8W 1/8W 1/8W 1/8W 1/8W (KV-M1430D ONLY)	R042 R043 R044 R045 R046 R047	1-216-081-00 1-215-900-11 1-216-105-00 1-216-089-00 1-216-081-00 1-216-079-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	22K 22K 220K 47K 22K	5% 5% 5% 5% 5%	1/10W 2W 1/10W 1/10W 1/10W	
JR131 JR133 JR134 JR135	1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 0 0	5% 5% 5%	1/8W 1/8W 1/8W 1/8W 1/8W	R048 R049 R050 R051 R052	1-216-079-00 1-216-202-00 1-216-073-00 1-216-250-00 1-216-295-00 1-216-065-00	METAL GLAZE  METAL GLAZE  METAL GLAZE  METAL GLAZE  METAL GLAZE  METAL GLAZE	18K 1.5K 10K 150K 0 4.7K	5% 5% 5% 5%	1/10W 1/8W 1/10W 1/8W 1/10W 1/10W	
JR137 JR139 JR144 JR146 JR147	1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 0	5% 5% 5% 5% 5%	1/8W 1/8W 1/8W 1/8W 1/8W	R053 R054 R055 R056 R056	1-216-049-00 1-249-395-11 1-216-057-00 1-216-041-00 1-249-434-11	METAL GLAZE CARBON METAL GLAZE METAL GLAZE CARBON	1K 15 2.2K 470 27K	5% 5% 5% 5% 5% 5%	1/10W 1/4W 1/4W 1/10W 1/10W	
JR148 JR149 JR150 JR151 JR152	1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 0	5% 5% 5% 5% 5%	1/8W 1/8W 1/8W 1/8W	R059 R060 R061 R062 R064	1-216-089-00 1-216-234-00 1-216-079-00 1-216-242-00 1-216-091-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	47K 33K 18K 68K 56K	5% 5% 5% 5%	1/4W 1/8W 1/10W 1/10W 1/8W 1/10W	
JR153 JR155 JR181 JR182 JR183	1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 0 0	5% 5% 5%	1/8W 1/8W 1/8W 1/8W 1/8W	R072 R075 R076 R077 R078	1-216-049-00 1-216-248-00 1-216-198-00 1-216-077-00 1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1K 120K 1K 15K 1K	555555555555555555555555555555555555555	1/10 1/8W 1/8W 1/8W 1/10W	
JR184 R001 R002 R003	1-216-296-00 1-216-069-00 1-216-081-00 1-216-081-00 1-216-083-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 6.8K 22K 22K	5% 5% 5%	1/8W 1/10W 1/10W 1/10W 1/10W	R079 R081 R082 R083 R084		METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE		555555555555555555555555555555555555555	1/104 1/8W 1/104 1/104 1/104	
R005 R006 R007 R008	1-216-206-00 1-216-254-00 1-216-190-00 1-216-049-00 1-216-049-00 1-216-198-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	2.2K 220K 470 1K	5% 5% 5% 5% 5%	1/8W 1/8W 1/8W 1/10W 1/10W	R087 R094 R095 R096 R097	1-216-027-00 1-216-077-00 1-216-065-00 1-216-065-00 1-216-085-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	120 15K 4.7K 4.7K 33K	555555555555555555555555555555555555555	1/100 1/100 1/100 1/100 1/100 1/100	
R010 R011 R012 R013	1-216-035-00 1-216-248-00 1-216-077-00 1-216-087-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1K 270 120K 15K	5% 5% 5% 5% 5%	1/8W 1/10W 1/8W 1/10W	R099 R100 R101 R102 R103	1-216-228-00 1-216-017-00 1-216-069-00 1-216-061-00 1-216-057-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	18K 47 6.8K 3.3K 2.2K	5%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%	1/8W 1/10G 1/10G 1/10G 1/10G	
R015 R016 R017 R018	1-216-230-00 1-216-049-00 1-216-081-00 1-216-065-00 1-216-065-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	22K 1K 22K 4.7K 4.7K	5% 5% 5% 5% 5%	1/8W 1/10W 1/10W 1/10W 1/10W	R104 R105 R106 R107 R108	1-216-057-00 1-216-109-00 1-216-081-00 1-216-073-00 1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	2.2K 330K 22K 10K 1K	5% 5% 5% 5% 5% 5%	1/10G 1/10G 1/10G 1/10G 1/10G	
R020 R021 R022	1-216-065-00 1-216-049-00 1-216-198-00	METAL GLAZE METAL GLAZE METAL GLAZE	4.7K 1K 1K	5% 5% 5%	1/10W 1/10W 1/8W	R109 R110	1-216-190-00 1-249-437-11	METAL GLAZE CARBON	470 47K	5% 5%	1/8W 1/4W	



REF.NO.	PART NO.	DESCRIPTION				REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK
R111 R112 R113 R114 R115	1-216-085-00 1-249-411-11 1-216-085-00 1-216-238-00 1-216-045-00	METAL GLAZE CARBON METAL GLAZE METAL GLAZE METAL GLAZE	33K 330 33K 47K 680	5% 5% 5%	1/10W 1/4W 1/10W 1/8W 1/10W		R336 R337 R338 R341 R342	1-216-059-00 1-216-073-00 1-216-073-00 1-216-061-00 1-216-041-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	2.7K 10K 10K 3.3K 470	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W
R116 R118 R119 R130 R131	1-249-409-11 1-216-041-00	METAL GLAZE METAL GLAZE CARBON METAL GLAZE	1K 270 680 220 470	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/4W 1/10W		R346 R347 R348 R349 R350	1-216-037-00 1-216-089-00 1-216-033-00 1-216-029-00 1-216-041-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	330 47K 220 150 470	55% %%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%	1/10W 1/10W 1/10W 1/10W 1/10W
R132 R136 R138 R139 R140	1-216-295-00 1-216-041-00 1-216-057-00 1-216-295-00 1-216-045-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 470 2.2K 0 680	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R351 R352 R353 R354 R355	1-216-043-00 1-216-039-00 1-249-438-11 1-216-081-00 1-216-049-00	METAL GLAZE  METAL GLAZE CARBON METAL GLAZE METAL GLAZE	560 390 56K 22K 1K	5% 5% 5%	1/10W 1/10W 1/4W 1/10W 1/10W
R141 R142 R143 R144 R147	1-216-029-00 1-216-063-00 1-216-033-00 1-216-065-00 1-216-073-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	150 3.9K 220 4.7K 10K	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R356 R357 R360 R363 R364	1-216-041-00 1-216-039-00 1-216-001-00 1-216-222-00 1-216-222-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	470 390 10 10K 10K	5% 5%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%	1/10W 1/10W 1/10W 1/8W 1/8W
R148 R149 R151 R152 R153	1-216-017-00 1-216-182-00 1-216-057-00 1-216-061-00 1-215-867-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL OXIDE	47 220 2.2K 3.3K 470		1/10W 1/8W 1/10W 1/10W 1/10W		R399 R402 R403 R404 R405	1-216-037-00 1-216-172-00 1-216-023-00 1-216-023-00 1-216-023-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	330 82 82 82 82 82	5% 5%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%%	1/10W 1/8W 1/10W 1/10W 1/10W
R199 R201 R202 R203 R204	1-216-057-00 1-216-073-00 1-216-057-00 1-216-298-00 1-247-741-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE CARBON	2.2K 10K 2.2K 2.2 150	5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/2W		R406 R407 R408 R409 R411	1-216-226-00 1-216-226-00 1-216-091-00 1-216-023-00 1-216-037-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	15K 15K 56K 82 330	5% 5%% 5%% 5%% 5%%	1/8W 1/8W 1/10W 1/10W 1/10W
R205 R206 R207 R303 R304	1-216-083-00 1-216-035-00 1-216-298-00 1-216-033-00 1-216-033-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	27K 270 2.2 220 220	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R412 R413 R414 R420 R421	1-216-037-00 1-216-037-00 1-216-041-00 1-216-182-00 1-216-449-11	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL OXIDE	330 330 470 220 56	5% 5% 5%	1/10W 1/10W 1/10W 1/8W 2W
R305 R306 R307 R308 R309	1-216-033-00 1-216-059-00 1-216-077-00 1-216-033-00 1-216-055-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE		5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R423 R424 R425 R426	1-216-095-00 1-216-222-00 1-216-033-00 1-216-045-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	82K 10K 220 680	5% 5% 5% 5%	(KV-M1431D ONLY)  1/10W  1/8W  1/10W  1/10W
R314	1-216-049-00 1-216-051-00 1-216-174-00 1-216-174-00 1-216-025-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	1 K 1.2 K 100 100 100	5% 5% 5%	1/10W 1/10W 1/8W 1/8W 1/10W		R431 R432	1-216-049-00 1-216-073-00 1-216-077-00 1-216-077-00 1-249-403-11	METAL GLAZE METAL GLAZE CARBON	15K 68	5%	1/10W 1/10W 1/10W 1/10W 1/4W
R315 R316 R317 R320 R321	1-216-047-00 1-216-089-00 1-216-202-00 1-216-057-00 1-216-023-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	820 47K 1.5K 2.2K 82	5% 5% 5%	1/10W 1/10W 1/8W 1/10W 1/10W	•	R433 R434 R435 R436 R437	1-216-079-00 1-216-029-00 1-216-033-00 1-216-089-00 1-216-085-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	18K 150 220 47K 33K	5% 5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W
R322 R323 R324 R325 R326	1-216-053-00 1-216-192-00 1-216-065-00 1-249-410-11 1-216-035-00	CARBON METAL GLAZE	1.5K 560 4.7K 270 270	5% 5%	1/10W 1/8W 1/10W 1/4W 1/10W		R501 R502 R503 R504 R505	1-247-743-11 1-249-437-11 1-216-017-00 1-216-073-00	METAL GLAZE CARBON CARBON METAL GLAZE METAL GLAZE	4.7K 220 47K 47 10K	5% 5% 5% 5% 5%	1/8W 1/2W 1/4W 1/10W 1/10W
R327 R328 R329 R330 R331	1-216-121-00 1-216-001-00 1-216-109-00 1-216-244-00 1-216-113-00	METAL GLAZE METAL GLAZE METAL GLAZE	1M 10 330K 82K 470K	5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W		R507 R508 R510 R511 R512	1-216-350-11 1-215-867-00 1-216-061-00 1-216-244-00 1-216-089-00	METAL OXIDE METAL OXIDE METAL GLAZE METAL GLAZE METAL GLAZE	1.2 470 3.3K 82K 47K	5% 5% 5% 5% 5%	1W F 1W 1/10W 1/8W 1/10W
R332 R333 R334 R335	1-216-270-00 1-216-091-00 1-216-067-00 1-216-001-00	METAL GLAZE METAL GLAZE	1M 56K 5.6K 10	5% 5% 5%	1/8W 1/10W 1/10W 1/10W		R513 R514 R515	1-216-053-00 1-216-051-00 1-216-683-11	METAL GLAZE METAL GLAZE METAL CHIP	1.5K 1.2K 22K	5%	1/10W 1/10W % 1/10W

The components identified by shading and mark  $\Lambda$  are critical for safety.

Replace only with part number specified.



REF. NO. PART NO. DESCRIPTION		REMARK	REF.NO. PART NO. DESCRIPTION REMARK
R516 1-216-095-00 METAL GLAZE R517 1-216-031-00 METAL GLAZE R518 1-216-033-00 METAL GLAZE R519 1-216-049-00 METAL GLAZE R520 1-216-258-00 METAL GLAZE R521 1-216-053-00 METAL GLAZE	82K 5% 1/10W 180 5% 1/10W 220 5% 1/10W 1K 5% 1/10W 330K 5% 1/8W 1.5K 5% 1/10W		R827
R522 1-215-863-11 METAL OXIDE R523 1-247-754-11 CARBON R524 1-216-099-00 METAL GLAZE R525 1-216-065-00 METAL GLAZE	100 5% 1W 1.5K 5% 1/2W 120K 5% 1/10W 4.7K 5% 1/10W		R1303 1-216-029-00 METAL GLAZE 150 5% 1/10W R1304 1-216-039-00 METAL GLAZE 390 5% 1/10W R1305 1-216-200-00 METAL GLAZE 1.2K 5% 1/8W R1306 1-216-059-00 METAL GLAZE 2.7K 5% 1/10W
R527 1-215-869-11 METAL OXIDE R532 1-216-081-00 METAL GLAZE R533 1-216-133-00 METAL GLAZE R534 1-216-069-00 METAL GLAZE R535 1-216-107-00 METAL GLAZE	22K 5% 1/10W 3.3M 5% 1/10W 6.8K 5% 1/10W 270K 5% 1/10W		R1308 1-216-045-00 METAL GLAZE 680 5% 1/10W R1309 1-216-049-00 METAL GLAZE 1K 5% 1/10W R1310 1-216-047-00 METAL GLAZE 820 5% 1/10W R1311 1-216-065-00 METAL GLAZE 4.7K 5% 1/10W
R539 1-216-049-00 METAL GLAZE R542 1-216-025-00 METAL GLAZE R543 1-249-408-11 CARBON R545 1-216-278-00 METAL GLAZE R548 1-216-049-00 METAL GLAZE	1K 5% 1/10W 100 5% 1/10W 180 5% 1/4W 2.2M 5% 1/8W 1K 5% 1/10W		R1312 1-216-222-00 METAL GLAZE 10K 5% 1/8W R1313 1-216-025-00 METAL GLAZE 10O 5% 1/10W
R601 A 1-205-909-11 WIREWOUND R602 1-214-923-00 CARBON R603 1-215-903-11 METAL OXIDE R604 1-247-752-11 CARBON R606 1-212-877-11 FUSIBLE	3.3 5% 10W 270K 5% 1/2W 68K 5% 2W 1K 5% 1/2W 68 5% 1/4W	F	RV001 1-238-012-11 RES, ADJ, CARBON 1K RV331 1-238-012-11 RES, ADJ, CARBON 1K RV501 1-238-016-11 RES, ADJ, CARBON 10K RV502 1-226-703-11 RES, ADJ, METAL GLAZE 10K RV503 1-238-019-11 RES, ADJ, CARBON 47K
R608 1-215-884-11 METAL OXIDE R609 1-207-905-00 WIREWOUND R611 1-214-915-00 CARBON R612 1-219-137-11 FUSIBLE R613 1-217-811-11 FUSIBLE	47 5% 2W 0.27 10% 2W 120K 5% 1/2W 0.33 5% 1/4W 0.47 5% 1/4W		RV504 1-238-019-11 RES, ADJ, CARBON 47K RV505 1-238-009-11 RES, ADJ, CARBON 220 RV801 1-238-019-11 RES, ADJ, CARBON 47K
R614 1-216-037-00 METAL GLAZE R615 1-216-013-00 METAL GLAZE R617 1-216-354-11 METAL OXIDE R620 1-216-465-11 METAL OXIDE R621 1-216-465-11 METAL OXIDE	330 5% 1/10W 33 5% 1/10W 2.7 5% 1W 27K 5% 2W 27K 5% 2W		
R626 A.1-216-238-91 METAL GLAZE R627 A.1-216-238-91 METAL GLAZE R628 1-218-265-11 METAL GLAZE R801 1-217-778-11 FUSIBLE R802 1-217-826-11 FUSIBLE	47K 5% 1/8W 47K 5% 1/8W 8.2M 5% 1W 1K 5% 1W 10K 5% 1/4W	F	<spark gap=""> SG801 1-519-422-11 GAP, SPARK</spark>
R803 1-216-355-11 METAL OXIDE R804 1-216-013-00 METAL GLAZE R805 1-216-065-00 METAL GLAZE R806 1-216-049-00 METAL GLAZE R807 1-216-075-00 METAL GLAZE	3.3 5% 1W 33 5% 1/10W 4.7K 5% 1/10W 1K 5% 1/10W 12K 5% 1/10W		<transformer>  T601 ★ .1-450-217-22 S.R.T- T603 ★ .1-421-776-21 LFT T604 ★ .1-424-078-11 TRANSFORMER, TRIGGER PULSE</transformer>
R808 1-216-091-00 METAL GLAZE R809 1-216-083-00 METAL GLAZE R810 1-216-095-00 METAL GLAZE R811 1-216-099-00 METAL GLAZE R812 1-217-778-11 FUSIBLE	56K 5% 1/10W 27K 5% 1/10W 82K 5% 1/10W 120K 5% 1/10W 1K 5% 1W		T605
R813 1-212-877-11 FUSIBLE R814 1-217-820-11 FUSIBLE R816 1-247-889-00 CARBON R817 1-216-071-00 METAL GLAZE	68 5% 1/4W 3.3K 5% 1/4W 270K 5% 1/4W 8.2K 5% 1/10W	l	<pre><thermistor> THP601A 1-806-165-12 THERMISTOR (POSITIVE)</thermistor></pre>
R818 1-202-830-00 SOLID R819 1-249-448-11 CARBON R820 1-217-811-11 FUSIBLE R821 1-216-059-00 METAL GLAZE R822 1-216-204-00 METAL GLAZE	10K 10% 1/2W 1.2 5% 1/4W 0.47 5% 1/4W 2.7K 5% 1/10W 1.8K 5% 1/8W		<tuner> TU101A. 1-693-093-11 TUNER (BT-3C421) TEKE4X001A <crystal></crystal></tuner>
R822 1-216-204-00 METAL GLAZE R824 1-215-863-11 METAL OXIDE R826 1-216-025-00 METAL GLAZE	2.7K 5% 1/10W 1.8K 5% 1/8W 100 5% 1W 100 5% 1/10W	F )	X001 1-577-619-11 VIBRATOR, CRYSTAL X332 1-567-131-00 OSCILLATOR, CRYSTAL

## KV-M1430D/M1431D RM-694







REF.NO. PART NO.	DESCRIPTION	REM	MARK	REF.NO.	PART NO.	DESCRIPTION				REMARK																																	
<ter< td=""><td>MINAL&gt;</td><td></td><td>1</td><td><b>Q7</b>09</td><td>8-729-200-17</td><td>TRANSISTOR 2S</td><td>A1091-</td><td>0</td><td></td><td></td></ter<>	MINAL>		1	<b>Q7</b> 09	8-729-200-17	TRANSISTOR 2S	A1091-	0																																			
YC1301 1-565-666-12	TERMINAL, S 4P				<res< td=""><td>ISTOR&gt;</td><td></td><td></td><td></td><td></td></res<>	ISTOR>																																					
*A-1638-022-A	C BOARD, COMPLETE ***********************************	*******	****	JW121 R701 R702 R703 R704	1-216-296-00 1-216-061-00 1-216-210-00	METAL GLAZE METAL GLAZE	0 3.3K 3.3K 680 680	5% 5% 5% 5%	1/8W 1/10W 1/8W 1/10W 1/10W																																		
*4-374-913-01	COVER (REAR LID), CV VOI			R705	1-216-017-00	METAL GLAZE	47		1/10W																																		
C700 1-137-146-11	ACITOR>	10% 250		R706 R707 R708 R709	1-216-017-00 1-216-017-00 1-216-198-00 1-216-196-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	47 47 1K 820	5% 5% 5% 5%	1/10W 1/10W 1/8W 1/8W																																		
C701 1-163-127-00 C702 1-163-127-00 C703 1-163-129-00 C704 1-163-005-11	CERAMIC CHIP 270PF CERAMIC CHIP 270PF CERAMIC CHIP 330PF CERAMIC CHIP 470PF	5% 50V 5% 50V 5% 50V 10% 50V		R710 R711 R712 R713	1-249-413-11 1-216-061-00 1-247-893-11 1-247-883-00	CARBON CARBON	470 3.3K 390K 150K	5% 5% 5%	1/4W 1/10W 1/4W 1/4W																																		
C705 1-163-005-11 C706 1-163-005-11 C707 1-123-947-00 C708 1-162-116-00 C709 1-136-666-11	CERAMIC CHIP 470PF CERAMIC CHIP 470PF BLECT 10MF CERAMIC 680PF FILM 0.01MF	10% 50V 10% 50V 20% 250V 10% 2KV 5% 1KV		R714 R715 R716 R717	1-216-198-00 1-216-049-00 1-202-824-00	SOLID	1K 1K 1K 3.3K	5% 5% 5% 10%	1/8W 1/8W 1/10W 1/2W																																		
C710 1-124-477-11 C711 1-163-009-11 C712 1-163-009-11 C713 1-163-009-11	BLECT 47MF CERAMIC CHIP 0.001MF CERAMIC CHIP 0.001MF CERAMIC CHIP 0.001MF	20% 16V 10% 50V 10% 50V 10% 50V		R718 R719 R720 R721	1-202-824-00 1-202-824-00 1-216-463-00 1-216-463-00	SOLID SOLID METAL OXIDE	3.3K 3.3K 12K 12K	10% 10%	1/2W 1/2W 2W 2W																																		
C714 1-162-318-11	CERAMIC 0.001MF	10% 500v		R722 R723 R726	1-216-463-00 1-249-398-11 1-202-719-00	METAL OXIDE CARBON SOLID	12K 27 1M	5% 5% 5% 10%	2W	F																																	
	PIN, CONNECTOR (5MM PITO PLUG. CONNECTOR (2.5MM)	CH) 2P 3P		R727 R728 R729 R731	1-202-838-00 1-202-842-11 1-216-349-00	SOLID SOLID METAL OXIDE	1	10% 10% 5%		F																																	
CNC74 *1-508-765-00	PIN, CONNECTOR (5MM PIT)	СН) ЗР		R732	1-202-719-00 1-216-262-00	SOLID METAL GLAZE	1 <b>M</b> 470K	-	1/2W 1/8W																																		
<010	DDE>			R734 R735 R736	1-216-057-00 1-216-057-00 1-249-421-11	METAL GLAZE METAL GLAZE CARBON	2.2K 2.2K 2.2K		1/10W 1/10W 1/4W																																		
D701 8-719-400-18 D702 8-719-400-18 D703 8-719-400-18 D704 8-719-400-18 D705 8-719-400-18	DIODE MA152WK				<var< td=""><td>IABLE RESISTOR</td><td>&gt;</td><td></td><td>2, 4</td><td></td></var<>	IABLE RESISTOR	>		2, 4																																		
	DIODE 188119 DIODE MAI52WK DIODE MA152WK			RV702 RV703 RV704	1-237-749-11 1-230-641-11 1-230-641-11	RES, ADJ, CARI	BON 221 AL GLA: AL GLA:	00 ZE 2.2 ZE 2.2	M																																		
D710 8-719-800-76	DIODE 1SS226			*****	*******	*********	*****	*****	**** ***	******																																	
	DIODE 1SS226 DIODE 1SS226			;	*A-1645-017-A	V BOARD, COMPI		KV-M14	31D ONL	Υ)																																	
<14	CK>				<cap< td=""><td>ACITOR&gt;</td><td></td><td></td><td></td><td></td></cap<>	ACITOR>																																					
J901 1-526-819-11	SOCKET, PICTURE TUBE			C1 C2	1-126-101-11 1-163-038-00	ELECT CERAMIC CHIP (	100MF 0.1MF			16V 25V																																	
<tr <="" td=""><td>ANSISTOR&gt;</td><td></td><td></td><td>C3 C4 C5</td><td>1-124-120-11 1-163-077-00 1-124-120-11</td><td>CERAMIC CHIP</td><td>220MF 0.1MF 220MF</td><td></td><td></td><td>16V 50V 16V</td></tr> <tr><td>Q701 8-729-230-49 Q702 8-729-230-49 Q703 8-729-230-49 Q704 8-729-906-70 Q705 8-729-906-70</td><td>TRANSISTOR 2SC2712-YG</td><td></td><td></td><td>C6 C7 C8 C9</td><td>1-163-038-00 1-163-235-11 1-163-235-11 1-163-235-11</td><td>CERAMIC CHIP ( CERAMIC CHIP 2 CERAMIC CHIP 2 CERAMIC CHIP 2</td><td>0.1MF 22PF 22PF</td><td></td><td>5<b>%</b> 5<b>%</b></td><td>25V 50V 50V 50V</td></tr> <tr><td>Q706 8-729-906-70</td><td>TRANSISTOR BF871</td><td></td><td>Ì</td><td>C10</td><td>1-163-038-00</td><td>CERAMIC CHIP (</td><td>O.1MF</td><td></td><td></td><td>25V</td></tr> <tr><td><b>Q</b>707 8-729-200-17 <b>Q</b>708 8-729-200-17</td><td></td><td></td><td></td><td>C11 C12</td><td>1-163-038-00 1-163-038-00</td><td>CERAMIC CHIP ( CERAMIC CHIP (</td><td></td><td></td><td></td><td>25V 25V</td></tr>	ANSISTOR>			C3 C4 C5	1-124-120-11 1-163-077-00 1-124-120-11	CERAMIC CHIP	220MF 0.1MF 220MF			16V 50V 16V	Q701 8-729-230-49 Q702 8-729-230-49 Q703 8-729-230-49 Q704 8-729-906-70 Q705 8-729-906-70	TRANSISTOR 2SC2712-YG			C6 C7 C8 C9	1-163-038-00 1-163-235-11 1-163-235-11 1-163-235-11	CERAMIC CHIP ( CERAMIC CHIP 2 CERAMIC CHIP 2 CERAMIC CHIP 2	0.1MF 22PF 22PF		5 <b>%</b> 5 <b>%</b>	25V 50V 50V 50V	Q706 8-729-906-70	TRANSISTOR BF871		Ì	C10	1-163-038-00	CERAMIC CHIP (	O.1MF			25V	<b>Q</b> 707 8-729-200-17 <b>Q</b> 708 8-729-200-17				C11 C12	1-163-038-00 1-163-038-00	CERAMIC CHIP ( CERAMIC CHIP (				25V 25V
ANSISTOR>			C3 C4 C5	1-124-120-11 1-163-077-00 1-124-120-11	CERAMIC CHIP	220MF 0.1MF 220MF			16V 50V 16V																																		
Q701 8-729-230-49 Q702 8-729-230-49 Q703 8-729-230-49 Q704 8-729-906-70 Q705 8-729-906-70	TRANSISTOR 2SC2712-YG			C6 C7 C8 C9	1-163-038-00 1-163-235-11 1-163-235-11 1-163-235-11	CERAMIC CHIP ( CERAMIC CHIP 2 CERAMIC CHIP 2 CERAMIC CHIP 2	0.1MF 22PF 22PF		5 <b>%</b> 5 <b>%</b>	25V 50V 50V 50V																																	
Q706 8-729-906-70	TRANSISTOR BF871		Ì	C10	1-163-038-00	CERAMIC CHIP (	O.1MF			25V																																	
<b>Q</b> 707 8-729-200-17 <b>Q</b> 708 8-729-200-17				C11 C12	1-163-038-00 1-163-038-00	CERAMIC CHIP ( CERAMIC CHIP (				25V 25V																																	

The components identified by shading and mark A are critical for safety.

Replace only with part number specified.





REF.NO. PART NO.	DESCRIPTION	REMARK	REF.NO.	PART NO.	DESCRIPTION			REMARK	
C14 1-124-927-11 C16 1-163-117-00	CERAMIC CHIP 0.1MF ELECT 4.7MF CERAMIC CHIP 100PF CERAMIC CHIP 100PF BLECT 4.7MF	25V 20% 50V 5% 50V 5% 50V 20% 50V	JR18 JR19 JR20 JR21 JR23	1-216-296-00 1-216-296-00 1-216-296-00 1-216-296-00 1-216-295-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 0 0 0	5% 5% 5% 5% 5%	1/8W 1/8W 1/8W 1/8W 1/10W	
C26 1-163-038-00 C27 1-163-117-00 C28 1-163-117-00 C29 1-163-117-00 C32 1-163-038-00 C33 1-163-038-00	CERAMIC CHIP 0.1MF CERAMIC CHIP 100PF CERAMIC CHIP 100PF CERAMIC CHIP 100PF CERAMIC CHIP 0.1MF	25V 50V 5% 50V 5% 50V 25V 25V	JR25 JR26 JR202 JR203 JR221	1-216-296-00 1-216-296-00 1-216-296-00 1-216-295-00 1-216-295-00 1-216-295-00	METAL GLAZE  METAL GLAZE  METAL GLAZE  METAL GLAZE  METAL GLAZE  METAL GLAZE  METAL GLAZE	0 0 0 0 0 0	5 % % % % % % % % % % % % % % % % % % %	1/8W 1/8W 1/8W 1/10W 1/10W 1/10W	
<pre></pre>		)	JR222 R1 R2 R3 R4	1-216-295-00 1-218-326-11 1-216-214-00 1-216-049-00 1-216-025-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	0 470 4.7K 1K 100	5% 5% 5% 5%	1/10W 1/2W 1/8W 1/10W 1/10W	
<pre></pre>			R5 R6 R7 R8 R9	1-216-047-00 1-216-001-00 1-216-083-00 1-216-071-00 1-216-308-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	820 10 27K 8.2K 4.7	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
D5 8-719-914-44 D6 8-719-400-18 D9 8-719-106-17	DIODE MA152WK DIODE RD6.8M-B2		R10 R11 R12 R13 R14	1-218-325-11 1-218-325-11 1-218-325-11 1-216-025-00 1-216-001-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	120 120 120 100 100	5% 5% 5% 5%	1/4W 1/4W 1/4W 1/10W 1/10W	
	IC SAA5246P/E/M4A IC FCB61C65L-70P		R15 R16 R17 R18 R19	1-216-013-00 1-216-013-00 1-216-013-00 1-216-025-00 1-216-025-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	33 33 100 100	5% 5% 5% 5%	1/10W 1/10W 1/10W 1/10W 1/10W	
L1 1-408-403-00 L2 1-408-407-00 L3 1-408-407-00 L4 1-408-407-00	INDUCTOR 6.8UH INDUCTOR 6.8UH		R21 R22 R23 R40 R42	1-216-013-00 1-216-168-00 1-216-214-00 1-216-065-00 1-216-049-00	METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE METAL GLAZE	33 56 4.7K 4.7K 1K	5% 5% 5% 5%	1/10W 1/8W 1/8W 1/10W 1/10W	
	LINK> LINK, IC (ICP-N15) 0.6A		R49 R50	1-216-049-00 1-216-296-00	METAL GLAZE METAL GLAZE	1 K 0	5% 5%	1/10W 1/8W	
<transistor></transistor>			<pre><variable resistor=""> rv1 1-238-012-11 res, adj, carbon 1k</variable></pre>						
Q1 8-729-900-53 TRANSISTOR DTC114EK Q2 8-729-920-92 TRANSISTOR 2SD2096-EF Q3 8-729-120-28 TRANSISTOR 2SC1623-L5L6 Q4 8-729-120-28 TRANSISTOR 2SC1623-L5L6 Q5 8-729-807-87 TRANSISTOR 2SB1295-UL6		RV1	<cry< td=""><td colspan="5"><crystal> -266-31 CRYSTAL VIBRATOR</crystal></td></cry<>	<crystal> -266-31 CRYSTAL VIBRATOR</crystal>					
Q6     8-729-807-87       Q7     8-729-807-87       Q9     8-729-901-04       Q10     8-729-901-01       Q11     8-729-901-01	TRANSISTOR 2SB1295-UL6 TRANSISTOR DTA114EK TRANSISTOR DTC144EK			*1-644-176-11	.,.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	*****	*****	********	
<resistor></resistor>			C2200	<pre><capacitor></capacitor></pre>					
JR01 1-216-295-00 JR02 1-216-295-00 JR03 1-216-295-00 JR08 1-216-295-00 JR09 1-216-295-00	METAL GLAZE 0 5% METAL GLAZE 0 5% METAL GLAZE 0 5%	1/10W 1/10W 1/10W 1/10W 1/10W			INECTOR>			۷۱۷	
JR11 1-216-295-00 JR14 1-216-296-00 JR15 1-216-296-00 JR17 1-216-295-00	METAL GLAZE 0 5% METAL GLAZE 0 5%	1/10W 1/8W 1/8W 1/10W	<jack> J2201 1-562-837-11 JACK</jack>						

## KV-M1430D/M1431D



REF.NO. PART NO.

DESCRIPTION

REMARK

<COIL>

L2201 1-408-409-00 INDUCTOR

10UH

\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*

## MISCELLANEOUS

Δ.1-426-145-21 COIL, DEGAUSSING
Δ.1-451-249-31 DEFLECTION YOKE (Y14NDA2)
1-452-032-00 MAGNET, DISK; 10MM φ
1-452-094-00 MAGNET, ROTATABLE DISK; 15MM φ
MAGNET, BMC

1-544-374-11 SPEAKER  $\triangle, 1\text{-}575\text{-}487\text{-}11$  . CORD, POWER (WITH NOISE FILTER)

V901 A . 8-735-555-05 PICTURE TUBE (A34JBU10X)

\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*

## ACCESSORIES AND PACKING MATERIALS

PART NO.

DESCRIPTION

REMARK

1-417-154-11 MATCHING TRANSFORMER, ANTENNA 1-501-372-21 ANTENNA, TELESCOPIC 3-754-807-11 MANUAL, INSTRUCTION \*4-201-082-01 CUSHION (UPPER) (ASSY) \*4-201-084-01 INDIVIDUAL CARTON \*4-384-927-01 BAG, PROTECTION

## REMOTE COMMANDER

1-465-562-12 CONTROL UNIT, REMOTE (RM-694) 4-035-049-01 COVER, BATTERY (FOR RM-694)

- copie identified by

The components identified by shading and mark A are criti-

Replace only with part number

cal for safety.

specified.